



When operating the hand controls, the ceiling lift LCD indicates "No Lim Sw!" and an audible alarm will continuously beep for 3 seconds.



#### Key:

Question

Action

Component Replacement

Supporting Document

Additional Context and Actions