Troubleshooting
Guide


Doc No. 990075-6

Freeway Transactive Xtra CTH Troubleshooting Guide Scenario:

Revision: A
Revision Date: 08/24

Hoist does not traverse

When operating the hand controls, the hoist has power and performs the usual lifting and lowering actions, but does not respond to traversing commands.







Component Replacement

Supportin Documen Additional Context and Actions