


When operating the hand controls, the ceiling lift LCD indicates "Up Inhibit!" and an audible alarm will repeat 3 times every 3 seconds, the LED will display a steady red.



Key:

Question

Action

Component Replacement

Supporting Document

Additional Context and Actions